



Illustrated Parts List Model Series 31P900

TYPE NUMBERS 0036 through 0671.


TABLE OF CONTENTS


Air Cleaner 5
Alternator 7
Blower Housing 5
Camshaft 2
Carburetor 4
Controls
Crankshaft 2
Cylinder 2
Cylinder Head 3
Electric Starter 7
Engine Sump 2
Flywheel 6
Fuel Supply 4
Gasket Set-Engine 2
Gasket Set-Valve 3
Governor Spring 7
Ignition
Intake Manifold 3
Kit-Carburetor Overhaul 4
Lubrication 3
Piston, Rings, and Connecting Rod 2
Valves




PRINTED IN U.S.A.


COPYRIGHT by BRIGGS & STRATTON CORPORATION All rights reserved. No part of this material may be reproduced or transmitted, in any form or by any means, electronic or mechanical, including photocopying, recording or by any information storage and retrieval system, without permission in writing from Briggs & Stratton Corporation.































NOTE: All stators use a No. 1119mounting screw.

NOTE: The proper flywheel part number and/or the alternator magnet size will determine the alternator type or output. See repair instruction manual for additional information.



31P900

REF. NO.	PART NO.	DESCRIPTION	REF. NO.	PART NO.	DESCRIPTION	REF. NO.	PART NO.	DESCRIPTION
1 2		Cylinder Assembly Kit-Bushing/Seal	29	791632	Rod-Connecting Used on Type No(s).	135	792022	Tube-Fuel Transfer Used on Type No(s).
3	 391086s	(Magneto Side)			0036, 0670.			0036, 0671.
3	×3910005	(Magneto Side)			791631 Rod-			698780 Tube–Fuel
4A	697188	Sump-Engine			Connecting			Transfer
5		Head-Cylinder			Used on Type No(s).			Used on Type No(s).
7		Gasket-Cylinder Head			0449, 0575, 0635,			0449, 0575, 0635,
9		Gasket-Breather			0652, 0671.			0652, 0670.
10	697157		32	791118		137A		Gasket-Float Bowl
11	607112	(Breather Assembly) Tube-Breather	33	70103/	(Connecting Rod) Valve-Exhaust	141B		Kit-Choke Shaft
12		Gasket-Crankcase	34		Valve-Intake	146	691639	Key-Timing
	A007 110	(.015" Thick)	35		Spring-Valve			Used on Type No(s) 0449, 0575, 0635,
		(Standard)			(Intake)			0652, 0671.
13	690360		36	691279	Spring-Valve			Note
		(Cylinder Head)			(Exhaust)			690979 Key-Timing
15	690946	Plug-Oil Drain	37		Guard-Flywheel			Used on Type No(s)
16	607516	(Square Head) Crankshaft	42 43		Keeper-Valve Slinger-Governor/Oil			0036, 0670.
10	09/310	Used on Type No(s).	45		Tappet-Valve	187	791766	Line-Fuel
		0036. 0670.	46		Camshaft			(15 Inches Long)(Cu
		Note	50		Manifold-Intake	187B	701905	To Required Length
		697127 Crankshaft	51★	∆ ●692137	Gasket-Intake	10/6	791605	(Formed)(10–1/4
		Used on Type No(s).	53	690227				Inches Long)(Cut to
		0449, 0575, 0635,		604440	(Carburetor)			Required Length)
20	★791892	0652, 0671.	54	691148	(Intake Manifold)	188	691693	
20	X/91092	(PTO Side)	73	697133	Screen-Rotating			(Control Bracket)
22	692125	,	74	697897	•	192		Adjuster-Rocker Ari
		(Crankcase			(Rotating Screen)	202	691841	Link-Mechanical
		Cover/Sump)	78	691003		209	602209	Governor Spring-Governor
23	693556	Flywheel	044	605405	(Flywheel Guard)	216		Link-Choke
		Used on Type No(s).	94A 95A	•690718	Kit-Idle Mixture	222		Bracket-Control
		0036, 0671. Note	95A	•090716	(Throttle Valve)	227	691374	Lever-Governor
		693557 Flywheel	98A	695408	Kit-Idle Speed			Control
		Used on Type No(s).	104A		Pin-Float Hinge	232		Spring-Governor Li
		0449, 0575, 0635,			Valve-Float Needle	238		Cap-Valve
		0652, 0670.	108B		Valve-Choke	240	394358s	Filter-Fuel
24		Key-Flywheel	117A	792296	Jet-Main			(White, 75 Microns) Used on Type No(s)
25	192507	Piston Assembly (Standard)	121A	792360	(Standard) Kit–Carburetor			0449, 0575, 0652,
		Note	'-'-	. 52553	Overhaul			0635, 0670.
		792648 Piston			(Nikki Carburetor)	240A	691035	Filter-Fuel
		Assembly	125A	792768	Carburetor			(Includes Paper
_		(.020" Oversize)			(Nikki Carburetor)			Element With A 40
26	791936	Ring Set	127A		Plug-Welch			Micron Rating)
		(Standard) Note	130A 131A		Valve-Throttle Kit-Throttle Shaft			Used on Type No(s) 0036, 0671.
		791947 Ring Set	131A		Float-Carburetor	265	691024	Clamp-Casing
		(.020" Oversize)	.554	UU-13 14	i iout Outbulletoi	200	001024	Ciamp Casing
27	698469	Lock-Piston Pin						
28		Pin-Piston						
		(Standard)	I			i		

<sup>Included in Engine Gasket Set–Ref. No.358.
Included in Carburetor Overhaul Kit–Ref. No. 121A.</sup>

 $[\]Delta$ Included in Valve Gasket Set–Ref. No 1095.

31P900

REF.	PART		REF.	PART		REF.	PART	311 900
NO.	NO.	DESCRIPTION	NO.	NO.	DESCRIPTION	NO.	NO.	DESCRIPTION
267	792629		415	690283	•	562	691119	
		(Casing Clamp)			(Sump)			(Governor Control
		Used on Type No(s).	431	697122	Elbow-Intake			Lever)
268	601005	0036, 0652. Casing-Control Wire			Used on Type No(s).	579	691029	Nut
200	091025	(Cut To Required	445	600003	0652. Filter-Air Cleaner	504	607440	(Starter Cable)
		Length)	445	090000	Cartridge	584	69/112	Cover-Breather Passage
269	691026	Wire-Control			(Non Washable)	601	791850	Clamp-Hose
		(Cut To Required			Note	614		Pin-Cotter
		Length)			697153 Filter-Air	616		Crank-Governor
270	691027				Cleaner Cartridge			Seal-O Ring
		(Control Wire Casing)			(Washable)			(Intake Manifold)
271		Lever–Control	462	691261	Washer	634B	●698779	Spring/Seal Assembly
276A 304		Washer-Sealing Housing-Blower			(Starter Cable)	635	691909	Boot-Spark Plug
304	030333	(Black)	474A	696459	Alternator	643	698401	Retainer–Air Filter
		Used on Type No(s).			(Dual Circuit) Used on Type No(s).	654	690958	
		0449, 0575, 0671.			0449, 0575, 0635,			(Carburetor)
		Note			0652, 0670.	691		Seal-Governor Shaft
		699704 Housing-	474B	696457		697	690372	
		Blower			(Tri Circuit)	710	600050	(Drive Cap) Pin-Locating
		(Black)			Used on Type No(s).	718 729A		Clip-Wire
		Used on Type No(s).			0036, 0671.	729A 729B		Clip-Wire
		0036, 0635, 0652, 0670.	501	691188	Regulator	741		Gear-Timing
305	697102				Used on Type No(s).	750	790832	_
		(Blower Housing)	500	604500	0036, 0671.			(Oil Pump Cover)
305A	697103		503 505	691532 691251	Strap-Starter	757	697607	Link-Counterweight
		(Blower Housing)	303	091231	(Governor Control	758		Counterweight
306		Shield-Cylinder			Lever)	759		Pin-Counterweight
307	691003		510	693699	Drive-Starter	783		Gear-Pinion
309	603551	(Cylinder Shield) Motor-Starter	513	692024	Clutch-Drive	789A	698329	Harness-Wiring
310	690323		523		Dipstick			Used on Type No(s). 0036, 0652, 0671.
	5555_5	(Starter Motor)	524		Seal-Dipstick Tube	797	693167	
311	497608	Brush Set	525	697085	Tube-Dipstick	131	090101	(Brush Retainer)
333	492341	Armature-Magneto			Used on Type No(s).	801	691283	Cap-Drive
334	691061				0036, 0671. Note	802		Cap-End
	4040==	(Magneto Armature)			697184 Tube-Dipstick	803		Housing-Starter
337	4910558	Plug-Spark			Used on Type No(s).			(Not Serviced
		691043 Plug-Spark			0449, 0575, 0635,			Separately, Order
		Used on Type No(s).			0652, 0670.			Starter Motor 693551)
		0652.	526	697088		830		Stud-Rocker Arm
356	697089	Wire-Stop			(Regulator)	842	*691031	Seal-O Ring
358		Gasket Set-Engine	544		Armature–Starter	847	700///3	(Dipstick Tube) Dipstick/Tube
363		Puller-Flywheel	552	697144	Bushing-Governor Crank	047	1 30440	Assembly
383		Wrench-Spark Plug	559	697561				Used on Type No(s).
385	694476	(Fuel Pump)	339	091 00 l	(Remote Choke Stop)			0036, 0671.
385A	690297	` '			Used on Type No(s).			Note
		(Fuel Pump)			0652.			790442 Dipstick/Tube
387	697090	Pump-Fuel	559A	693675	Screw			Assembly
387A		Pump-Fuel			(Remote Choke Stop)			Used on Type No(s).
404	691691	Washer			Used on Type No(s).			0449, 0575, 0635,
		(Governor Crank)			0652.			0652, 0670.

 Δ Included in Valve Gasket Set-Ref. No 1095.

[★] Included in Engine Gasket Set-Ref. No.358.
◆ Included in Carburetor Overhaul Kit-Ref. No. 121A.

31P900

	900							
REF. NO.	PART NO.	DESCRIPTION	REF. NO.	PART NO.	DESCRIPTION	REF. NO.	PART NO.	DESCRIPTION
851	692424	Terminal-Spark Plug	1023	791079	Cover-Rocker	1070	690372	Screw
868		Seal-Valve	1024	499054	Pump-Oil			(Flywheel Fan)
877	393456	Wire/Connector-	1026	692003	Rod-Push	1090		Retainer-Brush
		Alternator			(Intake)	1091		Cap-Limiter
		(Dual Circuit)			Note	1095		Gasket Set-Valve
877B	393537	Wire/Connector-			692011 Rod–Push	1119	691183	
		Alternator	1027	4020226	(Exhaust) Filter-Oil	1127	695407	(Alternator)
		(Tri Circuit)	1021	4323325	Used on Type No(s).	1127	093407	(Float Bowl)
878	398661	Harness-Alternator			0449, 0575, 0652,	1263	697124	Reed-Breather
		(Dual Circuit)			0671.	1264		
878A	691955	Harness-Alternator	1027A	696854	Filter-Oil			(Breather Reed)
		(Tri Circuit)			Used on Type No(s).	1266	⋆ ●691917	Seal-O Ring
914	691108				0036, 0635, 0670.			(Intake Elbow)
		(Rocker Cover)	1029		Arm-Rocker			Used on Type No(s).
918		Hose-Vacuum	1034		Guide-Push Rod			0652.
943	★ 690589	Seal-O Ring	1035	693784	Shaft-Pump	1266A	●69/123	Seal-O Ring
		(Oil Pump Cover)	1036		Label-Emissions (Available from an			(Intake Elbow) Used on Type No(s).
947A		Solenoid-Fuel			Authorized Briggs &			0652.
965		Cover-Oil Pump			Stratton Service	1267	697419	Latch-Blower Housing
967		Filter-Pre Cleaner			Dealer)			(Black)
968	698403	Cover-Air Cleaner	1040B	699852	Plate-Trim	1270	697156	Plug-AVS
0754	600500	(Black)	1044	698139	Screw			Counterweight
975A		Bowl-Float			(Flywheel)	1330	272147	Repair Manual
987A		Seal-Throttle Shaft	1051		Ring-Retaining			
1005 1017		Fan-Flywheel Screen-Oil Pump	1054		Tie-Cable			
1		Gasket-Rocker Cover	1058 1059		Operator's Manual Kit-Screw/Washer			
1022	KΔ2124135	Gasket-Hocket Cover	1039	096510	NII-Sciew/Wasilei			
1								
1								
1								
1								
		ring Cooket Cot. Dof. No. 0				ludad ia Va		

<sup>Included in Engine Gasket Set-Ref. No.358.
Included in Carburetor Overhaul Kit-Ref. No. 121A.</sup>

 $[\]Delta$ Included in Valve Gasket Set-Ref. No 1095.